
Toast 1-4 pcs







This recipe is available for:

- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4
- eikon® e4s

Accessories:

e4 Wire Rack DV0907





Ambient



4 Slices





From Scratch

Stage 1





. 0 %

Ingredients

1-4 slice

White Bread

1. Food Preparation

Place them direct on the rack.

2. Cooking Instruction Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the rack and serve.