


Crunchy Chik'n Burger 1 pce



eikon® e2s

 01:30





This recipe is available for:

- eikon® e2s HP (2000W)




Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

P
R
O
F
I
L
E

-  275 °C
-  Frozen -18°C
-  1 Piece
-  Partially Fried

Stage 1

-  01:30
-  50 %
-  100 %

R
E
C
I
P
E

Ingredients

135 g Chik'n Burger

1. Food Preparation

Place it on the tray.

2. Cooking Instruction

Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the tray and serve.