


Crunchy Chik'n Burger 2 pcs



eikon® e2s

 01:45





This recipe is available for:

- eikon® e2s HP (2000W)
- eikon® e4




Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black),
32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

P
R
O
F
I
L
E

-  275 °C
-  Frozen -18°C
-  2 Pieces
-  Partially Fried

Stage 1

-  01:45
-  40 %
-  100 %

R
E
C
I
P
E

Ingredients

270 g Chik'n Burger

1. Food Preparation
Place them on the tray.
2. Cooking Instruction
Cook as per oven profile.
3. Food Serving Instruction
Remove the cooked food from the tray and serve.